

PARTS LIST

ITEM	PART	DESCRIPTION	QTY	
1	ZD-1006	Wall Channels*	2	
2	ZV-935	Wall Anchors*	6	
3	#8X1-1/4"	8 x 1-1/4" Screws*	6	
4	#6X3/8"	6 x 3/8" Screws	8	
5	ZSS-3101	Headers	1	
6	ZSS-3101	Curbs	1	
7	ZV-902	Glass Support Blocks	1	
8		Inline Glass Panel	1	
9	ZV-909	Vertical Seal Vinyl	4	
10	ZV-906	Horizontal Seal Vinyl	4	
11	ZSS-1103	Inline Posts	1	
12	ZSS-1102	Header and Curb Fillers	2	

*NOTE: Items 1, 2 and 3 come with door stall wrap.

When ordering repair parts, please provide the following information:

1. Model Number
2. Part Number
3. Part Description
4. Finish Color

Required Tools:

To install your shower enclosure, you will need the following:

- Level
- #31 Drill Bit
- 3/16" Carbide Drill Bit (for tile walls)
- Phillips Screwdriver
- Silicone
- Hack Saw

