

When ordering repair parts, please provide the following information:

1. Model Number
2. Part Number
3. Part Description
4. Finish Color

BUTTRESS APPLICATION:

Tub/Shower Enclosures:

- PTE3/PSE3
- PTETE3/PTESE3
- PRETE3/PTESE3

NOTE:

Measure from both walls to outside edge of ZTE-1214 (Corner Post). Add 3/16" to this measurement for header length.

